

TruShot 2.0™ POWER CLEANER AND DEGREASER

EFFECTIVELY REMOVES ADHESIVES, OILS, GREASE, BAKED-ON OVEN SOILS, DIRT AND GRIME.



Powerful non-butyl, alkaline formulation with soil-lifting surfactants for exceptional cleaning. Ideal for a variety of non-porous surfaces such as walls, sinks, counter tops, cabinets and glass surfaces and exterior surfaces of kitchen equipment.

TO CLEAN:

- Spray and wipe using a wet sponge, cloth, paper towel or brush, rinsing frequently with warm water
- Allow product to penetrate one minute on heavily soiled surfaces
- Rinsing with potable water is required



USE INSTRUCTIONS

Refer to label for complete use instructions.

INSTRUCTIONS



CLICK
Durable Snap-in technology



FILL
Refill with unheated tap water



CLEAN
Portable lightweight comfort

SAFETY PRACTICES TO FOLLOW

It's good business practice to ensure that your employees have read and understood the product labels and Safety Data Sheet before using this product. The label use directions and SDS contain important hazard warnings, precautionary statements and first aid procedures. Ensure WHS compliance with pre-labeled cartridges.

This information is available on-line at www.scjp.com or by calling 1800 090 330.

Improper use of product may damage surfaces and may result in physical harm to the end user.

Use only as directed.
Always read label and product information before use.

PRODUCT CODE	PACKAGE SIZE DESCRIPTION	IN-USE LITRES
341461	4x 296 mL Cartridge	296 mL concentrate = up to 12.3 in-use litres
311981	4x TruShot 2.0™ trigger sprayer	

PRODUCT CODE	COLOUR	pH	pH AT DILUTION	DENSITY	FRAGRANCE	SHELF LIFE
341461	Clear	14	11.3	1.03g/cm ³	Fresh	4 years

Incompatible Materials: Do not mix with bleach or any other cleaners. Strong bases.