


A ASSEMBLY INSTRUCTIONS:


1
Slide cartridge into dispenser until it clicks.




2
Lift fill lid. Add tap water to fill line (MAX line). Close lid.



3
Turn the nozzle to use the product. Two spray types are available: wide for broad surface coverage, and narrow for targeted cleaning.




4
Apply according to "Directions for Use" on cartridge label.




B DIRECTIONS FOR CHANGING CARTRIDGES:


1
Press release button. Remove cartridge.




2
Press once after the cartridge has been removed.



3
Insert new cartridge.



4
Spray 5 times to prime.




FOR BEST RESULTS:
Store upright. Do not spray without chemistry cartridge attached or with empty water reservoir. Maintain effective water and chemistry levels to avoid inconsistent spraying.

C DIRECTIONS FOR STORAGE:

1
Empty all the water from the tank at least every 24 hours.



2
Once cleaning is completed, set the nozzle to the OFF position (X).



3
Store with the water tank always open and empty. Keep the sprayer & the cartridges upright.

