

EZ CARE FLOOR COATING REMOVER

GROUND BREAKING CLEANER TECHNOLOGY COMPATIBLE WITH AN AUTO SCRUBBER. The EZ CARE Floor Coating Remover is designed to remove up to four coats of EZ Care floor coating in one pass by using an auto scrubber.

- Liquifies EZ Care Floor Coating for fast removal of up to four coats in one pass.
- Eliminates conventional manual stripping and exposure to corrosive stripping chemicals.
- Increases productivity by reducing the time and labor needed for a full removal and recoat.
- Streamlines the floorcare workflow, reduces crew size, and simplifies training vs. conventional stripping.



EZ Care Floor Coating Remover is part of the EZ CARE floor care system and is specifically designed to be used along with **SC Johnson Professional® EZ CARE Floor Coating**, **EZ CARE Heavy Duty Scrub Pads** and **EZ CARE High Speed Conditioning and Polish Pad**.

Compatible with an Auto Scrubber

SKU	DESCRIPTION	CASE PACK	IN USE GALLONS PER BOTTLE
362837	EZ Care Floor Coating Remover	6x32oz	1:64 Dilution Up to 16 Gal. per bottle



Use Instructions:

Removes up to 4 coats of SC Johnson Professional® EZ CARE Floor Coating in one pass.

USE COLD WATER FOR ALL APPLICATIONS. DUST MOP AREA PRIOR TO CLEANING TO REMOVE CONTAMINANTS.

1. PLACE PROPER BLOCKADES

Floors will be slippery when wet or contaminated with foreign materials.

2. PREPARE the EZ Care Floor Coating Remover according to label instructions.

3. TURN ON cold water to fill wringer bucket or auto scrubber.

STRING MOP APPLICATION:

Apply liberal amounts of remover solution to floor and let dwell for 10 minutes. Ensure remover solution does not dry during dwell time.

AUTOMATIC SCRUBBER MACHINE:

Install proper pad to scrubbing machine. Apply liberal amounts of remover solution to floor while scrubbing. Let dwell for 10 minutes. Ensure remover solution does not dry during dwell time.

4. AFTER INITIAL 10 MIN DWELL, re-wet as necessary and LET DWELL 5 MIN PRIOR TO SCRUBBING. On first pass, scrub with swing machine or auto-scrubber without picking up remover solution. Second pass, mop or auto-scrub floor while picking up remover solution.

5. REPEAT step 4 if necessary.

Note: Rinse floor with clean water. Allow floor to completely dry before applying SC Johnson Professional® EZ CARE Floor Coating. Do not use on wood, cork or decorative concrete, as surfaces may be damaged.

May be used as an alkaline cleaner on uncoated concrete, quarry tile, unglazed ceramic, natural stone, rubber, brick, and slate.

SAFETY PRACTICES TO FOLLOW

It's good business practice to assure that your employees have read and understood the product labels and Safety Data Sheet before using this product. The label use directions and SDS contain important hazard warnings, precautionary statements and first aid procedures. This information is available on-line at www.scjp.com or by calling 800-248-7190.

FOR BEST RESULTS: DO NOT USE UNDILUTED. Best to apply in a well-ventilated area. Do not apply on surfaces with temperatures below 50°F (10°C). Not intended for outdoor spaces. Not intended for use on wood. Test in an inconspicuous area for adhesion on concrete, polished concrete and highly polished marble and granite.

NOTE: EZ Care Floor Coating Remover does not contain intentionally added PFAS*.

PRODUCT SPECIFICATION

Color	Orange; Clear at dilution
pH	13.53
pH at dilution	11.3
Density	8.25 g/cm ³
Fragrance	Fresh
Shelf-Life	2 years
Substrate compatibility	VCT, Vinyl Asphalt, Sheet Vinyl, LVT, Rubber, Linoleum, Marmoleum, Vinyl Asbestos, Terrazzo, Concrete (non-decorated), Honed and Polished Granite, Honed and Polished Marble, Natural Stone, Brick, Slate, Quarry Tile, Unglazed Ceramic
Incompatible materials	Do not mix with bleach or any other household cleaners or strong bases.



EZ CARE FLOOR COATING REMOVER
Can be applied and removed with an auto scrubber



*PFAS are perfluoroalkyl and polyfluoroalkyl substances, which are a class of fluorinated organic chemicals containing at least one fully fluorinated carbon atom.